

# Poly Canopy Assembly Instructions



Treker 4200/4400 NT & ST

Manual No. 701-103M

## Before You Start



When you see this symbol, the subsequent instructions and warnings are serious – follow without exception. Your life and the lives of others depend on it!

**IMPORTANT:** Before you begin, read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

Your Land Pride accessory kit is exclusively designed for your Land Pride vehicle. Please read the installation instructions and operator's manual thoroughly before beginning. Installation of any item is easier if the vehicle is clean and free of debris.

## General Information

These instructions apply to the Poly Canopy Kit for the following options listed below:

- 701-025A Poly Canopy Top Grey Treker NT
- 701-026A Poly Canopy Top Black Treker NT
- 701-023A Poly Canopy Top Grey Treker ST
- 701-024A Poly Canopy Top Black Treker ST

**Kit Components:** Your kit should include the following;

<u>QTY.</u>	<u>Part Description</u>
1	Poly Canopy
4	¼-20 Screws
4	Rubber coated clamps
4	¼-20 Nylon lock nuts
4	1" Flat washers
1	Instruction sheet

Please contact your local land pride dealer for any missing hardware. REF. Hardware bag for ST Poly Canopy (Pt No. 701-087B)  
NT Poly Canopy (Pt No. 701-110B)

### Tools Required:

- Phillips head screw driver
- 7/16" wrench

**Approximate Installation Time:** 15 Minutes

## Assembly Instructions

**IMPORTANT:** Perform all tasks correctly and completely.

1. Park vehicle on flat surface, move gear shift lever to park, set park brake, turn off engine and remove ignition key.
2. Position canopy onto the cab frame, with the front edge of the top resting against the front most cab frame bar. The back of the canopy overhangs the cab frame to fully protect the operator. Install rubber coated clamps over cab frame tubing from the underside of the canopy as illustrated. Use the ¼-20 screws, washers and ¼-20 nylon lock nuts to secure the canopy to the cab frame, please refer to the illustration.
3. Check to be sure that canopy is securely fastened to the cab frame, adjust as necessary. Extra fasteners and clamps may be required for extreme use.

