



Installation Instructions

Before you begin, read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

Kit Components:

QTY.	Part Description
2	Side Enclosures
1	Rear Enclosure
12	Snap studs with locking nut

Installation Supplies:

- Drill
- 3/16" Drill Bit (for snaps)
- 11/32 Wrench
- Phillips head screwdriver

IMPORTANT: Your Land Pride accessory kit is exclusively designed for your Land Pride vehicle. This enclosure attaches to the vehicle using adhesive Velcro and snaps that are supplied within this kit. Please read the installation instructions and operator's manual thoroughly before beginning. Installation of any item is easier if the vehicle is clean and free of debris.

Approximate Installation Time: 45 Minutes

INSTALLATION INSTRUCTIONS

1. Before starting, remove roof from vehicle. Windshield should be in place. Begin by holding either side of the enclosure in place on the vehicle and take note of where to place adhesive Velcro on the vehicle.
2. Begin at top of side closure and apply adhesive Velcro strips to underside of roll cage, as shown in Figure 1 at location (A). Be sure to position top notches so they align with brackets for roof.
3. Apply adhesive Velcro on the rear of the roll cage, as shown in yellow in Figure 2. Position notches to align with brackets on rear cage.
4. Apply front adhesive Velcro on the windshield as the enclosure overlaps the windshield. Be sure fabric fits snug / tight when working from top to bottom. Reposition and adjust the placement of the enclosure until it aligns properly prior to applying any Velcro at the bottom.
5. Apply remaining Velcro straps as it lays over the windshield, cab frame, and body of vehicle. Refer to Figure 1 for approximate side Velcro location.

6. Before beginning any snap installation, be sure the enclosure is positioned properly. Install the male snaps by marking where the center point of the female snap that is mounted on the fabric meets the body or windshield. Using a 3/16" drill bit, drill a hole in the fender or windshield, install the snap and tighten with the locking nut using a 11/32" wrench.
7. Install the rear panel on the outside of the rear cage (if applicable) attaching Velcro straps as necessary. Note, there is no adhesive Velcro needed for installation of the rear panel. Portions of the rear panel Velcro will overlap and attach to the side panels. Use self tapping snap studs (2) for rear, mount snaps in body of vehicle just below cage.

Warning:

Be careful to position snaps accurately as it can affect fitting of your enclosure.

Note:

Always check the overall effect the adhesive Velcro placement will have on part alignment before committing to adhesion.



Figure 1



Figure 2