

Tire Chains Front & Rear Assembly Instructions



Treker 4200/4400 NT/ST and 4210/4410 ST Series

Manual No. 701-138M

Before You Start



When you see this symbol, the subsequent instructions and warnings are serious - follow without exception. Your life and the lives of others depend on it!

IMPORTANT: Before you begin, read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

Your Tire Chains Front & Rear is exclusively designed for your Land Pride NT & ST Treker. Please read these installation instructions and your NT & ST Treker Operator's Manual thoroughly before beginning. Especially read information relating to safety concerns. Also included in the Operator's Manual is important information on operation, adjustment, troubleshooting, and maintenance for this attachment (some manual sections do not apply to all accessories).

General Information

These assembly instructions apply to the following Tire Chains Accessories listed below:

701-005A Tire Chains Rear- Size C

701-006A Tire Chains Front- Size B

Further Assistance

Your dealer wants you to be satisfied with your new Tire Chains Front & Rear. If for any reason you do not understand any part of this manual or are not satisfied with the service received, the following actions are suggested:

1. Discuss the matter with your dealership service manager making sure he is aware of any problems you may have and that he has had the opportunity to assist you.
2. If you are still not satisfied, seek out the owner or general manager of the dealership, explain the problem and request assistance.
3. For further assistance write to:

Land Pride Service Department
1525 East North Street
P.O. Box 5060
Salina, Ks. 67402-5060

E-mail address
lpservicedept@landpride.com

Assembly Instructions

Follow directions for installing chains.

Apply as tightly as possible by hand for maximum life.

1. Lay chains out flat, cross chain hook eyes up and SPECIAL fastener on the outside of tire. Tuck the first cross chain (side chain ends without fasteners) under tire. (SEE DIAGRAM #1)

2. Lay chain over tire, cross hook eyes up and SPECIAL fastener on the outside of tire. Tuck the first cross chain (side chain ends without fasteners) under tire. (SEE DIAGRAM #2)

3. Move tractor until SPECIAL fastener is axle high. (SEE DIAGRAM #3)

4. Fasten INSIDE hook to proper link of INNER side chain that will allow the cross chain to be straight across the tire tread. (SEE DIAGRAM #4)

5. Remove slack and hook outside fastener. Make chain as tight as possible by hand without the use of tools. Drive approximately 1/4 mile, stop and retighten. (SEE DIAGRAM #5)



CAUTION

*Check owners' manual for correct tire pressure.
Maintain a tight to snug fit throughout use. Adjust periodically to keep cross chains straight across tire tread.
Excess links of side chain can be removed or wired back.
ACCELERATE SLOWLY! DO NOT EXCEED 5 MPH.
Avoid locking wheels when braking.
REMOVE tire chains on bare roads.
Avoid hitting curbs with tire chains.*

Assembly Instructions

